


THV COMPOZIT CASEMENT CLEANING & CARE




Labeled are vital parts of your THV Casement Window. Becoming familiar with them will help you better follow these instructions.

1. Screen
2. Security Lock
3. Operating Sash
4. Right Hand Casement Operator
5. Casement Frame (Lockside)
6. Casement Frame (Hingeside)



SECURITY LOCK--Flip up to unlock, flip down to lock. Use security lock, not sash operator, to fully close operating sash.



SASH OPERATOR--Rotate to open. NEVER operate with security Lock engaged. When closing, **DO NOT OVER TIGHTEN**; this may damage the closure mechanism.

Cleaning Instructions

To open the THV Casement Window, first flip up the security locks, then simply rotate the sash operator (clockwise on right hinged casements or counter clockwise on left hinged casements) until the sash is opened to the 90° position. Remove the screen. Clean the outside window pane first, close and clean the inside. Clean the glass in your THV Casement Window with any glass cleaner, or simply wipe with clean water. The Compozit will require routine cleaning. Use a mild detergent with a soft cloth to clean off light soil. To close, rotate operator opposite the direction used to open until sash gently contacts the casement frame. Then flip down the security lock to fully seal operating sash. Reinstall the screen.

DO NOT OVERTIGHTEN SASH WITH OPERATOR CRANK. THIS MAY RESULT IN DAMAGE TO CLOSURE MECHANISM.

Screens

Each THV Casement Window features a non-corroding fiber glass cloth screen that slips in and out easily. (Note: See your dealer for full panel screen removal instructions).

Casement Routine Maintenance

Important Note: Periodically clean any debris buildup off sill track and hardware for smooth operation. The operating sash must be in open position to perform this cleaning.